

Technical Bulletin

DESCRIPTION / FEATURES:

FLOOR MEDICS POULTICE BOOSTER

is a fine, absorptive clay and Nano - scale abrasive cleaning powder designed for the removal of deep-set oil / grease & stubborn stains.

■ **USES:**

- Recommended for use on Natural Stone, Agglomerate, Porcelain and all Tiles material

■ **AVAILABLE SIZES:**

Poultice Booster is available in 1Kg / Tub.

■ **COVERAGE:**

- Approximately 75 to 210 sq. ft. (7 m² to 20 m²) per kilogram depending on method of application and procedure followed

■ **METHOD OF APPLICATION:**

- **Read entire label before using**
- **TEST A SMALL AREA**, according to application instructions, to determine desired results

■ **FOR REMOVING DEEP SET OIL AND GREASE STAINS:**

- Mix (38 to 88 grams) of Poultice Booster with Recommended Solvent or Chemical liquid to form a thick, workable paste
- Apply a 1/4-inch (6 mm) thick layer of paste directly over stain with at least a 1-inch (25 mm) overlay beyond edge of stain
- Cover with plastic film or wax paper (if surface subjected to traffic)
- Allow paste to stand on stain for 24 or till paste totally dry
- Remove Poultice Booster without scratching surface and wash off residue with Floor Medics Stone Cleaner.
- Repeat procedure if necessary.

■ **FOR REMOVING STAIN ON POLISHED PORCELAIN OR DENSE GRANITE:**

- Protect surrounding areas from splattering to minimize cleanup
- Apply Recommended Chemical on surface Dwell for 1-2 minutes and sprinkle Poultice Booster onto a manageable area making thin slurry. Buff Surface till almost dry.
- Spread mixture on small section of about 10 sq. ft. (1 m²) and agitate by white pad or with low RPM (175- 300 RPM) Scrubbing machine, using a white nylon scrub pad. Keep surface Damp throughout buffing process.
- Remove Poultice Booster solution with clean towels or sponge and rinse twice with clean water. A wet-dry vacuum may be used.
- Polish surface dry with clean, dry towels or buff with soft buffing pad.
- On vertical or countertop surfaces, hands apply Poultice slurry, scrubbing with white nylon scrub pad.
- Rinse with clean water and buff dry with clean towels.



■ **LIMITATIONS:**

- Extreme care should be taken with Polish marble as they are normally softer surface
- Light abrasive action or high RPMs on the surface of these marbles may dull the high polished finish
- Do not allow Poultice Booster to come in contact with any non recommended surface

▲ **CAUTION:**

• **KEEP OUT OF REACH OF CHILDREN**

- Irritant
- Contains calcite clay
- Avoid breathing dusts
- Do not take internally.
- Rubber Gloves and eye protection should be worn during application.
- **INHALATION:** Move to fresh air
- **IF INGESTED:** Do not induce vomiting. Drink 1 to 2 glasses of water. Seek immediate medical attention.
- **EYE CONTACT:** Flush thoroughly with water for 15 minutes. If irritation persists, seek medical attention.
- **SKIN CONTACT:** Wash skin with soap and water. Remove contaminated clothing

Copy right of Floor Medics