

Technical Bulletin

DESCRIPTION / FEATURES:

FLOOR MEDICS STONE RESTORER

is a unique blend of polishing compounds design to restore and maintain worn calcium based, polished stone surfaces. Removes light surface scratches and etched marks.

■ USES:

- Recommended for use on marble, limestone, terrazzo and calcium based stones.

■ AVAILABLE SIZES:

- Stone Restorer is available in 1Kg / Tub

■ COVERAGE:

- Approximately 200 to 300 sq ft.(20-30sqm) per kg

■ METHOD OF APPLICATION:

- Read entire label before using.
- TEST A SMALL AREA, according to application instructions, to determine desired results.

EQUIPMENT:

- 1) 175 to 300 RPM floor machine or hand polish machine
- 2) Synthetic fiber white or red floor pads
- 3) Floor Medics Stone Restorer & Stone Cleaner
- 4) Protective plastics & tapes
- 5) Wet-dry vac
- 6) Mop and bucket
- 7) Squeegee

Procedure:

- 1) Sweep or vacuum surface.
- 2) Remove or stripped surface of existing sealers or coatings.
- 3) Protect baseboards, carpet, etc. with protective plastic or tape.
- 4) Wet an area no larger than 20 sq. ft. with clean water and place 2 tablespoons of Stone Restorer in the center.
- 5) Using a synthetic fiber white or red floor pad, work the area in a side-to-side motion with a 175 to 300 RPM floor machine.
- 6) The consistency of the slurry should be fluid enough to achieve even coverage. If the slurry becomes too dry, add water as required.
- 7) For large areas, work in small sections and be sure to overlap the sections to achieve an even polish.
- 8) Continue until the required polish has been achieved - squeegee slurry from a small area to check for desired results prior to removing slurry.
- 9) Use wet-dry vacuum to remove slurry and rinse thoroughly with Floor Medics Stone Cleaner.
- 10) Polish dry with a new polishing pad or cotton bonnet.



■ **LIMITATIONS:**

- Do not allow product to come in contact with any non-recommended surface.
- May not be suitable for some green marbles.
- Severely damaged or worn polished marble may require resurfacing.
- Not intended for use on granite, porcelain, ceramic tile, or cultured marble.

■ **HANDLING AND STORAGE:**

- Close container after each use.
- Store in original container only.
- Unused, Store product is freeze-thaw stable.

▲ **CAUTION:**

- **KEEP OUT OF REACH OF CHILDREN.** Do not take internally.
- Sweep area to remove any loose dirt or soil
- Rubber Gloves and eye protection should be worn during application.
- **IF INGESTED:** Do not induce vomiting. Drink 1 to 2 glasses of water. Seek immediate medical attention.
- **EYE CONTACT:** Flush thoroughly with water for 15 minutes. If irritation persists, seek medical attention.
- **SKIN CONTACT:** Wash skin with soap and water. Remove contaminated clothing

Before



After



Copy right of Floor Medics