

Technical Bulletin

DESCRIPTION / FEATURES:

FLOOR MEDICS SOLVENT CLEANER

is an effective blended solvent based liquid formulated to remove most sealers, urethane coatings, synthetic finishes, adhesives, and paints. Also dissolves deep-set stains and removes heavy grease buildup. It may also be used full-strength for removal of deep-set oil/grease & stubborn stains.

■ USES:

- Recommended for use on granite, porcelain tiles and other stone & tile surfaces.

■ AVAILABLE SIZES:

- Stone Restorer is available in 1Litre or 5Litre / Bottle

■ COVERAGE:

- Depending on condition of floors treated, approximately 75 to 200 sq ft. (7m² to 20m²) per 1 Litre

■ METHOD OF APPLICATION:

- Read entire label before using.
- TEST A SMALL AREA, according to application instruction to determine desired results.

FLOOR:

1. Sweep, vacuum or dust mop the floor surface.
2. Apply a liberal amount of Solvent Cleaner to a small manageable or affected area
3. Apply solution onto surface, allow to dwell 1 to 2 minutes and scrub surfaces with nylon bristle brush or pads
4. Wipe up residue with clean, absorbent white cotton towels or sponge
5. Wash/Rinse surface with Floor Medics Neutral Cleaner to remove any remaining residue.

■ LIMITATIONS:

- Do not allow product to come in contact with any non-recommended surface.

■ HANDLING AND STORAGE:

- Close container after each use.
- Store in original container only.
- Unused, Store product is freeze-thaw stable.

▲ IN CASE OF FIRE:

- Use Carbon Dioxide, Dry Chemical or Foam

▲ CAUTION:

- FLAMMABLE LIQUID & VAPOUR
- Keep away from heat, sparks & flame
- Avoid prolong breathing vapour
- Use only with adequate ventilation



- **KEEP OUT OF REACH OF CHILDREN.** Do not take internally.
- Rubber Gloves should be worn during application.
- **IF INGESTED:** Do not induce vomiting. Drink 1 to 2 glasses of water. Seek immediate medical attention.
- **EYE CONTACT:** Flush thoroughly with water for 15 minutes. If irritation persists, seek medical attention.
- **SKIN CONTACT:** Wash skin with soap and water. Remove contaminated clothing

Before



After



Copy right of Floor Medics